

How to remove tape residue & adhesives

1. 2. 3. 4.
Spray On -- Soak -- Scrub -- Wipe Dry

1. Spray the tape residue or adhesive with SafeSolv
2. Let soak for 1-5 minutes
3. Scrub with the Aero Scrubber or soft brush
4. Wipe with towel
5. Repeat until the tape residue or adhesive is completely removed
6. Clean the area with Wash Wax ALL (Blue).

NOTE:

SafeSolv is a non-toxic biodegradable way to remove tape residue and adhesives.